


1.5" from tunnel floor
to top of floor plate



Center of ceiling pin
located at center of
floor turntable

