



# Image Processing of Digital X-Ray Images

N. Shashishekhar  
V.J. Technologies, Inc.

# Contents

- ✦ Introduction
- ✦ Image Enhancement
- ✦ Noise Reduction
- ✦ Special Filters
- ✦ Image Registration
- ✦ Automated Defect Recognition

# Introduction

- ✦ Modern X-ray imaging systems produce digital images
- ✦ This enables sophisticated image processing to be applied to these images
- ✦ Image processing can reveal significant information, not easily discernible from the raw, acquired image

# Need for Image Enhancement

- ✦ X-ray digital detectors have high dynamic range (12-16 bits)
- ✦ Often required to detect low contrast, small sized features of interest
- ✦ Part geometry impacts viewing and interpretation
  - ✦ Makes low contrast detail difficult to detect
  - ✦ Increases inspection cycle time





Acquired




## Automated Defect Enhancement (ADE)




Comparison:  
Contrast-Brightness Adjustment



Acquired




Contrast-Brightness Adjustment






ADE




Acquired





ADE




# Noise Reduction

- ✦ Low contrast, fine detail enhancement also enhances noise
- ✦ Reducing noise increases contrast and detail visibility
- ✦ Challenge is to reduce noise without losing detail (detail preserving)




ADE





ADE + Noise Reduction



Acquired






ADE



ADE + Noise Reduction





ADE





ADE + Noise Reduction




Acquired

01 10 07 0



ADE

01/07/00





ADE + Noise Reduction



Acquired

ADE







ADE + Noise Reduction



+ Contrast-Brightness  
Adjustment




Acquired + Noise Reduction +  
Contrast-Brightness Adjustment




# Comparison (Gaussian filter)

Acquired + Gaussian smoothen (1) +  
Contrast-Brightness Adjustment




Acquired + Noise Reduction +  
Contrast-Brightness Adjustment




# Comparison (Gaussian filter)

Acquired + Gaussian smoothen (2) +  
Contrast-Brightness Adjustment




Acquired + Noise Reduction +  
Contrast-Brightness Adjustment






# Comparison (Median filter)

Acquired + Median filter + Contrast-Brightness Adjustment




Acquired + Noise Reduction + Contrast-Brightness Adjustment







Acquired



ADE






## ADE + Noise Reduction





Acquired






# Special Filters

The background of the slide is a dark blue field filled with several interlocking gears of different sizes. The gears are rendered in various shades of blue, from a very dark, almost black blue to a lighter, medium blue. They are arranged in a way that suggests a complex mechanical system, with some gears partially overlapping others. The overall effect is a technical and industrial aesthetic.


GM 6.2L P/5071

31 OCT 05

#52930197 I3 SC 06 I-14




GM 6.2L P/5071  
31 OCT 05  
#52930197 I3 SC 06 I-14







M 62L P 50/1  
11 OCT 05  
52930197 G SC 06 114









# Image Registration


- ★ Image registration is the process of aligning images to relate corresponding features
- ★ Application primarily in Automated X-Ray Inspection
- ★ Methods
  - ✱ Invariant Feature Correspondence (Fiducials)
  - ✱ Optical Flow

Login: admin


Administrator Help



Inspectio...











# Air-Bag Inflators

## Auto-Ignition Cartridge Verification




# Automated Defect Recognition (ADR)

- ★ Fully automated X-ray image analysis done by computer
- ★ Automatic, semi-automatic and operator assist modes
- ★ Automatic part identification (ability to inspect different part types in random order)



# Automated Defect Recognition (ADR)




# Automated Defect Recognition



# Automated Defect Recognition

on System  
Administrator Options Image Help  
Defect Display Image: u222lh L4 4.TIF Decision: REJECT





# Castings

