

The image features the Olympus logo, which consists of the word "OLYMPUS" in a bold, blue, sans-serif font. Below the logo is a horizontal yellow line that tapers at both ends. Underneath the line is the tagline "Your Vision, Our Future" in a smaller, blue, sans-serif font. The entire logo and tagline are centered on a white background. The background is framed by dark blue curved shapes at the top and bottom, with a light gray curved line separating the white central area from the blue borders.

OLYMPUS

Your Vision, Our Future

Flexible Videoscope/Borescopes Articulation

**Pushing the limits of articulation and
maintaining reliability**

Frank Lafleur – Product Manager

July 15, 2014



How does Olympus lead in the world of reliable and precise articulation.

- Quick Olympus Overview
- Basic Videoscope Structure
- The Challenges Faced by Inspection in Space
- Zero Gravity Scope (VAU)
- Types of Articulation, Their benefits and drawbacks
 - Low force direct articulation IPLEX Ultralite by Joystick
 - Power Assisted Articulation IPLEX Series by Joystick
 - Servo Articulation IPLEX SX Series by Joystick
 - Geared Manual Articulation Olympus Medical
 - Pneumatic Articulation
 - Hydraulic Articulation
 - Multi Articulation
- Bringing it all together – Know How

Track Record of Innovation in Remote Visual Inspection

1999 Eye-Trek



1949 – First
Gastrocamera



1964 – First
Gastrocamera
With Fiberscope



1982 – First
Medical Video
And Ultrasound
Endoscopes



2002 – First
High definition
Videoscope
system



1970s



Fiberscope
Rigid-scope

1980s



1990s



Videoscope

2001



IPLEX SA

2004



MX

2007



FX

2009



LT/LX/MXII

2011



UltraLite

2013



IPLEX RT/RX

2009 – First 3D
Measurement Laser
Microscope




2007 – First
High Resolution
Capsule endoscope



Basic Videoscope Structure


Olympus constantly fine tunes the basics of Videoscope Structure, with small advances to make scopes more user friendly. From power assisted True Feel Articulation to Taper Flex[®] Technology.



Control Unit




Base Unit





Challenges of Inspection in Space

- Inertia – Why won't it stop?
- Air – or lack there of effecting pressures in the construction.
- Handling – Hard to be dexterous with these....
- Temperature, variations – Precision is a relative thing.




Zero Gravity – VAU Project


- Olympus has worked with NASA on Projects to advance the limits of remote visual equipment



Types of Articulation

- Having established the challenges of the inspection, review of the technologies available is critical to evaluating an effective solution.
 - What are the benefits and complications
- 

Low Force Direct Articulation



- PROS

- Direct Articulation provides exceptional control and feel
- Stresses are kept to a minimum

- CONS

- No automation possible
- Force limited by thumb, length and articulation amount is therefore limited



- Olympus Patent 8,758,230 B2
June 24, 2014

Power Assisted Articulation


- PROS

- Power Assisted Articulation provides good control and feel
- Power assistance provides greater range capability
- Stresses are kept to a balance

- CONS

- No automation possible
- More complex/larger


- Olympus Patent 6,793,622 B2
Sept 21, 2004



Servo Articulation

- PROS

- Exceptionally powerful for amazing length
- Remote and automated control are possible




- CONS

- No feel or feedback, relative slow response
- Forces applied can prematurely stretch cables
 - Olympus Patent 7,104,951 B2
Sept 12, 2006



Direct Geared Articulation




PROS

- Exceptional feel and control
- Stresses are kept to a minimum

• CONS

- No automation possible
- Force limited by thumb, short length only
- 2 way articulation with thumb only.



- Olympus Patent 4,286,585
Sept 1, 1981

Pneumatic Articulation


- PROS

- Operational at very long distances
- Minimal components to stretch/wear

- CONS

- Slower reaction times
- Requires more real-estate inside insertion tube
- Susceptible to outside pressures

- Olympus Patent Filed



Multi-Articulation


• PROS

- Exceptional feel and control
- Ability to reach and arrive at locations previously impossible or difficult
- Stresses on the cables kept to a minimum


CONS

- No automation possible in current configuration
- Complex control

- Olympus Patent 8,777,843
July 15, 2014



Bringing it all together

- No solution is perfect for inspection in space
 - There are pros and cons to all the technologies
 - Sources outside Olympus may have more advanced electronic and intelligence systems
 - So why is Olympus here, and what can we provide to the efforts of in space inspection?
- 

We Bring Know How

- With hold over 1374 endoscope patents in the US alone.
- This know how provides the most durable and reliable core mechanisms in the endoscopic world. Critical for anything going to space.
- We are constantly seeking methods to make our customers, their interests and patients to have the very best in outcome and reliability.
- Perhaps together with other technology leaders, we can work towards serving both NASA's needs, and our customers.

Any Questions?

Frank Lafleur

frank.lafleur@olympusndt.com

