

Updates of the Lithium-ion Space Chemistry, and COTS Testing


NASA Space Battery Workshop Huntsville, AL November 27-29th, 2018

Chad Deroy












Congratulations InSight!!!!



EAGLEPICHER TECHNOLOGIES




EaglePicher Provides Reliable, Flexible, Power and Energy Dense Solutions for High Technology Applications

Innovating, Investing and Growing





Heritage in Mission-Critical Applications




Serving Mission-Critical Aerospace, Defense, Aviation and Medical Battery Markets





Life Testing Updates

Updated Chemistries for Space application




This document does NOT contain technology or technical data controlled under either the International Traffic in Arms Regulations (ITAR) or the Export Administration regulations (EAR)





NCP12-4


BOL Test; Discharge Capacity



This document does NOT contain technology or technical data controlled under either the International Traffic in Arms Regulations (ITAR) or the Export Administration regulations (EAR)



BOL Test; 20°C DC Resistance



This document does NOT contain technology or technical data controlled under either the International Traffic in Arms Regulations (ITAR) or the Export Administration regulations (EAR)


EAGLEPICHER¹ TECHNOLOGIES



- The NCA chemistry NCP12-4 cells were placed on life cycling per LiTP-6245 that was previously run on the NCP12-2 NCO chemistry cells.
 - Per para. 5.1 Real-time life cycling at 30°C
 - 4320 cycles per round
 - –2.4 amp charge to 4.1Vdc, tapering for a total time of 55 min
 - -13 amp discharge for 4.5 min
 - -Open Circuit rest for 30.5 min
 - Capacity and DC Resistance
 - -Every 1000 Cycles




END-OF-DISCHARGE VOLTAGE



This document does NOT contain technology or technical data controlled under either the International Traffic in Arms Regulations (ITAR) or the Export Administration regulations (EAR)




NCP12 Life Cycle Capacity Checks @30°C






NCP12 Capacity Loss Comparison



This document does NOT contain technology or technical data controlled under either the International Traffic in Arms Regulations (ITAR) or the Export Administration regulations (EAR)



Life Cycle 50% SoC DC Res. @30°C




This document does NOT contain technology or technical data controlled under either the International Traffic in Arms Regulations (ITAR) or the Export Administration regulations (EAR)

EAGLEPICHER¹ TECHNOLOGIES



NCP12 DC Resistance Comparison




This document does NOT contain technology or technical data controlled under either the International Traffic in Arms Regulations (ITAR) or the Export Administration regulations (EAR)

EAGLEPICHER⁺ TECHNOLOGIES



NCP43-4


BOL Test; Discharge Capacity



This document does NOT contain technology or technical data controlled under either the International Traffic in Arms Regulations (ITAR) or the Export Administration regulations (EAR)



BOL Test; 20°C DC Resistance



This document does NOT contain technology or technical data controlled under either the International Traffic in Arms Regulations (ITAR) or the Export Administration regulations (EAR)




43AH LIFE CYCLING @30°C

- + The NCA chemistry NCP43-4 cells were placed on life cycling per LiTP-6245 that was previously run on the NCP43-2 NCO chemistry cells.
 - Per para. 5.3 Real-time life cycling at 30°C
 - 4320 cycles per round
 - -11.0 amp charge to 4.1Vdc, tapering for a total time of 53.3 min
 - -14.0 amp discharge for 36.7 min
 - Capacity and DC Resistance
 - -Every 1000 Cycles




NCP43-4 End-of-Discharge Voltage



This document does NOT contain technology or technical data controlled under either the International Traffic in Arms Regulations (ITAR) or the Export Administration regulations (EAR)


EAGLEPICHER¹ TECHNOLOGIES

NCP43 Life Cycle Capacity Checks @30°C






NCP43 Capacity Loss Comparison






Life Cycle 50% SoC DC Res. @30°C





NCP43-4 DC Resistance Comparison







COTS Cell Evaluations

COTS EVALUATION- TEST PLAN

- CAT Tests (All Cells)
 - Use (or determine) the 1C rated capacity for C rate calculation
 - -~* 50% SOC should be half of the rated capacity at 1C/25°C
 - Use datasheet to select operating voltage range
 - Low Rate Continuous
 - Continuous 25°C
 - » C/5 Charge, C/5 Discharge 3 cycles, 72hr stand
 - » C/5 Charge, C/2 Discharge with DCR at 100% and ~50% SOC* (at 1hr)
 - » C/5 Charge, 1C Discharge
 - » C/5 Charge, 5C Discharge
 - » C/5 Charge, ~20A Discharge
 - Continuous 0°C
 - » C/5 Charge, C/5 Discharge 3 cycles
 - » C/5 Charge, C/2 Discharge with DCR at 100% and ~50% SOC* (at 1hr)
 - » C/5 Charge, 1C Discharge
 - » C/5 Charge, 5C Discharge
 - » C/5 Charge, ~20A Discharge
 - Continuous -20°C
 - » C/5 Charge, C/5 Discharge 3 cycles
 - » C/5 Charge, C/2 Discharge with DCR at 100% and ~50% SOC* (at 1hr)
 - » C/5 Charge, 1C Discharge
 - » C/5 Charge, 5C Discharge.
 - » C/5 Charge, ~20A Discharge



COTS EVALUATION- TEST PLAN CONT.

-40% DoD LEO Life Cycling @ 20°C

- » Characterization Cycles @20°C (4.1 V to 3.0V)
 - » C/5 Charge, C/5 Discharge (3 cycles)
 - » C/5 Charge, C/2 Discharge with DCR at 10% increments until 0% SoC
- Start LEO Cycle
 - » C/5 to 4.0V tapered to C/10
- LEO Cycles
 - » 0.8C Discharge for 30 minutes
 - » C/2 Charge for 60 minutes tapering current to 4.0V
 - » Repeat the LEO discharge/charge cycling in 200 cycles have completed
 - » Once 1000 LEO cycles have completed repeat *Characterization Cycles*
 - » Continue LEO cycling and *Characterization Cycles until...*?
- -HOLD cells here until any mission specific testing is considered.

- Cell DPA, Document Construction



SETUP FOR COTS EVALUATION




12-cell test fixture



Foam Insulation




CAPACITIES @ VARIOUS °C





DC RESISTANCE @ VARIOUS °C





This document does NOT contain technology or technical data controlled under either the International Traffic in Arms Regulations (ITAR) or the Export Administration regulations (EAR)

ONGOING AND FUTURE WORK

- + Next Generation of Lithium-ion Space Chemistry for these prismatic cell designs yields improvements
 - Increased BOL capacity
 - Decreased capacity loss over life
 - Reduction of 3-times in impedance growth, following LEO cycling
 - Physical dimensions allow for Off-the-shelf designs, utilizing this chemistry, gaining improvements for the next generation of space vehicle.
- + COTS solutions are being developed for certain applications.



Thanks to all the employees at EaglePicher



To learn more visit www.eaglepicher.com.

